



To continue its program of quality and design improvement, the manufacturer reserves the right to change specifications, design or prices without notice and without incurring obligation.

## ASSEMBLY INSTRUCTIONS

18515E1 Spacer Kit

Form No. 19929P1

Effective Date: 11-1-72

This kit is used with the 11925E1 Rear Wheel Weights on all tractors with reversed rear wheels.

1. Install the bolts of the spacer kit ( $\frac{1}{2}$ -13 x  $4\frac{1}{4}$ ) through the rim of the wheel.
2. Install 18514P1 spacer on each bolt.
3. Place each weight section on 2 bolts.
4. Secure in place using flat washer and locknut.

Printed in U. S. A.