



GRAVELY®

CONVERTIBLE 7 1/2
ILLUSTRATED
PARTS LIST

Custom series with standard transmission

 **GRAVELY®**


A Division of Clarke-Gravely Corporation
GRAVELY LANE — CLEMONS — NORTH CAROLINA 27012



<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	12592P1	Gasket, Chassis Rear
2	10122A1	Crankcase Comp.
3	124546	Key Woodruff 5/32 x 5/8 Hard No. 6
4	12619P1	Bushing, Camshaft
5	12631P1	Bushing, Camshaft Bearing
6	12721P1	Stud, Idler Gear
7	12608P1	Stud, Cylinder
8	12618P1	Stud, Guide
9	12584P1	Dowel, Crankcase
10	12607P1	Stud, Cylinder
11	12629P1	Bushing, Oil Pump Bearing
12	12625P1	Gear, Spur, Idle
13	12626P1	Bearing, Ball .590 x 1.3780 x .433
14	12627P1	Stud, Idle Gear Bushing
15	120394	Washer, Flat 13/32 x 13/16 x .065
16	138542	Washer Lock 3/8 Int Tooth
17	120369	Nut, 3/8-24 Hex
18	12719P1	Gear, Oil Pump Master
19	12628P1	Gear, Oil Pump Drive
20	431788	Key Woodruff 1/16 x 1/4 Hard No. 201
21	120381	Washer, Lock 3/8 Sp Light
22	124925	Nut Jam 3/8-24 Hex
23	18073P1	Body, Bearing and Pump
24	12720P1	Gear, Oil Pump Idle
25	12716P1	Cap, Pump
26	180016	Bolt Hex 1/4-20 x 1/2
27	180033	Bolt Hex 1/4-20 x 1-3/8
28	12576P1	Flywheel
29	12583P1	Bearing, Drive Pinion St.
30	12580P1	Shaft, Drive Pinion
31	124549	Key Woodruff 3/16 x 3/4 Hard No. 9
32	12582P1	Nut, Flywheel
33	12581P1	Gear, Spur, Timing
34	12577P1	Pin, Crank
35	10124A1	Rod, Connecting
36	12609P1	Bushing, Connecting Rod
37	12610P1	Bushing, Connecting Rod
38	14592A1	Piston Assembly (Includes 39 & 40)
	14050A1	Piston .005
	14051A1	Piston .010
	14052A1	Piston .015
	14053A1	Piston .020
	14054A1	Piston .025
	14055A1	Piston .030
39	13075P1	Pin, Piston 5763
40	13076P1	Lock, Piston Pin
41	12579P1	Washer, Spreader Bolt
42	12578P1	Bolt, Spreader
43	124934	Nut Jam 1/2-20 Hex
44	102592	Screw Set 3/8-16 x 3/8 Hex Socket
45	12615P1	Camshaft, Exhaust
46	12698P1	Shaft, Mag Extension
47	12623P1	Gear, Camshaft
48	12630P1	Camshaft, Intake
49	12622P1	Seal, Oil Camshaft
50	12624P1	Plug, Expansion
51	102570	Screw Set 1/4-20 x 3/8 Hex Socket

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
52	12617P1	Plunger, Valve
53	12735P1	Screw, Tappet
54	18318P1	Gasket
55	12616P1	Guide and Cover
56	120423	Washer, Lock 1/4 Int Tooth
57	120613	Nut, Jam 1/4-28 Hex
58	120376	Nut 5/16-18 Hex
59	189300	Bolt Hex 5/16-18 x 5-1/2
60	12984P1	Bearing, Ball .984 x 2.449 x .669
61	7106P1	Shim, Axle Bearing Cap .020
62	7107P1	Shim, Axle Bearing Cap .005
63	13491P1	Seal, Bearing Cap
64	13022P1	Connector, Pump Outlet 1/4 Dia.
65	12676P1	Connector, Pump Inlet 5/16 Dia.
66	12152P1	Hex Socket Hd
67	180018	Bolt Hex 1/4-20 x 5/8
68	15366A1	Guides, Cylinder w/Valve
69	12736P1	Guide, Intake Valve
70	12737P1	Guide, Exhaust
71	12612P1	Exhaust Valve
72	12611P1	Valve, Inlet
73	12731P1	Gasket, Washer, Valve Spring
74	12738P1	Locator, Valve Spring
75	12732P1	Gasket, Upper Cover
76	12613P1	Spring, Valve
77	5741P1	Cap, Valve Spring
78	5742P1	Key, Valve Spring Cap
79	12614P1	Gasket, Cylinder Bottom
80	120382	Washer Lock 3/8 Sp
81	5735P1	Gasket, Cylinder Head
82	10877P1	Head, Cylinder
83	180082	Bolt Hex 5/16-18 x 1-3/8
84	12734P1	Valve, Cover Gasket
85	12733P1	Cap, Valve Cover
86	121749	Screw Mach 8-32 x 5/16 Rd Hd
87	12621P1	Gasket, Exhaust Manifold
88	12605P1	Manifold, Intake
89	180020	Bolt Hex 1/4-20 x 3/4
90	120423	Washer, Lock 1/4 Int Tooth
91	14594A1	Ring Set Standard
	14595A1	Ring Set .005
	14596A1	Ring Set .010
	14597A1	Ring Set .015
	14598A1	Ring Set .020
	14599A1	Ring Set .025
	14600A1	Ring Set .030
92	12606P1	Manifold, Exhaust
93	12998P1	Gasket
94	10878A1	Carburetor
95	13739P1	Plate Throttle
96	14185P1	Spring
97	13700P1	Needle Idle Adj.
98	13742P1	Throttle Lever Assembly
99	14223P1	Throttle Shaft Lever Asm. Bendix C2916
100	13710P1	Float, Axle
101	13720P1	Float
102	13926P1	Washer, Fuel Valve


<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
103	13757P1	Valve, Fuel Asm.
104	13736P1	Gasket
105	13693P1	Fuel Bowl
106	13717P1	Jet, Adj. Main
107	13927P1	Washer Jet Adj.
108	13750P1	Jet, Main
109	13928P1	Washer Main Jet
110	13731P1	Retainer
111	13728P1	Bracket, Choke Clamp Asm.
112	13734P1	Bracket Mounting Screw
113	13725P1	Shaft, Choke Lever Asm.
114	13932P1	Screw
115	13922P1	Nut
116	13722P1	Plate Choke
117	14196P1	Plug, Cup
118	13929P1	Washer Jet
119	13755P1	Jet Discharge
120	13719P1	Jet, Vent Well
121	13730P1	Plug, Shaft Hole
122	13703P1	Bushing, Throttle Shaft
123	13698P1	Venturi
124	13940P1	Screw, Throttle Stop
125	13752P1	Jet Idle
126	180077	Bolt Hex 5/16-18 x 3/4
127	180087	Bolt Hex 5/16-18 x 2
128	13415P1	Nipple, Pipe 1 x 2
129	8227P1	Muffler
130	10965P1	Plug, Spark
NS	13452P1	Starter Strap
NS	10895A1	7.6 H.P. Service Engine
131	13938P1	Bowl to Body Screw
132	20002P1	Plug, 1/8 Zenith
133	19999P1	Washer
134	20000P1	Seal, Felt Zenith
135	20001P1	Clip, Zenith
136	14222P1	Throttle, Body Assy
137	14030P1	Seal, Rubber



ITEM NO.	PART NO.	DESCRIPTION
1	10388P1	Chassis
2	13456P1	Pin, Roller
3	12727P1	Baffle, Filler Neck
4	12593P1	Neck, Oil Filler
5	10390P1	Bearing, Roller Cup
6	12647P1	Shaft, Worm
7	12668P1	Key, Worm
8	13495P1	Gear, Worm 6 Lead
	13494P1	Gear, Worm 4 Lead
	13496P1	Gear, Worm 8 Lead
9	12332P1	Bearing, Roller, Cone
10	10389P1	Bearing, Roller, Cone
11	12333P1	Bearing, Roller Cup
12	12635P1	Nut, Bearing Adjustment
13	12648P1	Nut, Adjusting
14	180018	Bolt Hex 1/4-20 x 5/8
15	12681P1	Shaft, Clutch Actuating
16	10618P1	Bushing
17	10663P1	O Ring 3/4 x 1
18	12694P1	Washer
19	180016	Bolt Hex 1/4-20 x 1/2
20	12595P1	Shim, Axle Housing .005
21	12596P1	Shim, Axle Housing .020
22	12597P1	Gasket
23	12128P1	Housing, Axle
24	12130P1	Bearing, Roller Cup
25	120384	Washer, Lock 1/2 Sp
26	180173	Bolt Hex 1/2-13 x 1
27	12594P1	Washer, Oil Drain
28	13624P1	Bolt, 1/2-13 x 1 Hex Hd Nylon Insert
29	120396	Washer, Flat 17/32 x 1-1/16 x .095
30	13498P1	Gear, Worm 6 Lead
	13497P1	Gear, Worm 4 Lead
	13499P1	Gear, Worm 8 Lead
31	12559P1	Block, Differential Thrust
32	12556P1	Pin, Spider Pinion
33	271089	Key Woodruff 1/8 x 3/8 Hard No. 213
34	12666P1	Gear, Bevel, Spider Pinion
35	12667P1	Block, Drive
36	12555P1	Gear, Bevel, Differential
37	12129P1	Housing, Differential
38	12131P1	Bearing, Roller, Cone
39	181623	Bolt Hex 5/16-24 x 2-3/4
40	138538	Washer Lock 5/16 Int Tooth
41	120368	Nut Hex 5/16-24
42	12636P1	Cup, Gear
43	12632P1	Gear, Spur, Internal
44	12644A1	Cup, Clutch Assembly
45	12677P1	Rod, Clutch Slide L.H.
46	12678P1	Rod, Clutch Slide R.H.
47	12663P1	Spacer, Spring Pin Plate
48	14922A1	Fwd Rev. Planet Assembly
49	12633P2	Plate, Model L Front Pin
50	12637P1	Gear, Spur, Sun Pinion
51	14923A1	Quill Bushing Assembly
52	12662P1	Bushing, .875 x 1.000 x 2
53	120375	Nut Hex 1/4-20

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
54	12639P1	Gear, Spur, Orbit
55	11630P1	Pin, Orbit Gear, Bronze
56	12655P1	Spacer, Front Pin
57	12656P1	Gear, Spur, Reverse, Idler
58	12657P1	Bushing, .375 x .685 x .516, Rev. Idler
59	12658P1	Bolt, Reverse Idler
60	12643P1	Spacer, Bolt (Right Hand)
61	12654P1	Reverse Gear Cone
62	12591P1	Gasket, Chassis Front
63	17186P1	Casting, Advance Asm.
64	14921A1	Thrust Bushing Assembly
65	10619P2	Stud
66	180735	Bolt Hex 5/16-18 x 3-1/4
67	11298P1	Shaft, Pinion
68	12465P1	Washer, Rubber
69	180081	Bolt, Hex 5/16-18 x 1-1/4
70	12660P1	Dog, Attachment
71	12601P1	Block, Trunnion
72	10687P2	Glide, Shipper Shaft
73	12661P1	Shaft, Shipper
74	18318P1	Gasket
75	180089	Bolt, Hex 5/16-18 x 2-1/4
76	94194550	Nut Lock 5/16-18 Washer Insert Hex
77	10146A1	Body, Oil Strainer
78	12707P1	Washer, Nut, Oil Strainer
79	124944	Nut Jam 5/8-18 Jam
80	10377P1	Axle, Standard
81	9246P1	Bearing, Cones
82	9245P1	Bearing, Race
83	10382P1	Shim .020
84	10383P1	Shim .005
85	10384P1	Gasket
86	10379P1	Cap, Bearing
87	12590P1	Seal, Oil
88	180077	Bolt Hex 5/16-18 x 3/4
89	12645P1	Plate, Rear Thrust
90	15947A1	Gear, Orbit, Pin Plate Assembly
91	10472A1	Rear Pin Plate Assembly
92	12652P1	Bushing, Rear Pin Plate
93	11707A1	Bushing, Sun Gear Assembly
94	14220P1	Bushing, Sun Gear
95	12641P1	Pin Spacer
96	12642P1	Spacer, Bolt (Left Hand)
97	13413P1	Washer, Lock Lilt
98	12680P1	Rod, Clutch Slide
99	12679P1	Rod, Clutch Slide
100	12649P1	Spacer, Rear
101	12672P1	Key, Hub
102	12671P1	Hub, Wheel
103	13412P1	Nut Lock 5/8-18 Esna
104	10586P1	Guide, Dipstick
105	10147A1	Dipstick
106	120369	Nut Hex 3/8-24
107	274301	Ball, Locator
108	12586P1	Spring, Attachment Throwout
109	102591	Screw Set 3/8-16 x 1/4 Hex Socket
110	12319P1	Body, Shifter

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
111	12320P1	Dowel, Shifter Body
112	12603P1	Gasket, Boss Cover Attachment
113	180175	Bolt Hex 1/2-13 x 1-1/4
114	120378	Nut Hex 1/2-13
115	10142A1	Wheel, Diamond Tread Assembly
116	13836P1	Tire, Tractor DT
117	12674P1	Disc, Inner Wheel
118	12673P1	Disc, Wheel
119	13573P1	Tube, Tire, Tractor
120	94286380	Bolt Hex 3/8-16 x 5/8
121	124829	Nut, Jam 3/8-16 x 5/8
122	10884A2	Breather, Oil Assembly
NS	10141A1	Wheel, Super Grip Assembly
NS	13835P1	Tire Tractor GG
NS	11637P1	Puncture Proof Tube




<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	10137A1	Valve, Relief
2	8230P1	Connector, Relief Valve
3	272123	Nut Jam 7/16-20 Hex
4	8231P1	Body, Relief Valve
5	12702P1	Spring
6	13570P1	Ball
7	13571P1	Nut
8	13572P1	Sleeve
9	6732P1	O Ring 7/16 x 5/8 x 3/32
10	12723P1	Bracket, Oil Filter
11	13065P1	Tee, Discharge Line
12	13064P1	Adapter, Oil Gauge
13	114798	Elbow 1/4 Ball Sleeve Asm.
14	120386	Washer, Flat 5/16 x 47/64 x .065
15	180021	Bolt Hex 1/4-20 x 7/8
16	8259P1	Line, Oil
17	12708P1	Bracket, Cable
18	12325P1	Grommet, Shifter
19	5745A1	Pulley, Fan Drive
20	5784P1	Stud, Drive Pulley
21	121358	Nut Hex 5/8-18
22	13507P1	Elbow
23	12725P1	Line Oil
24	20114P1	Coupling, Magneto
25	180081	Bolt Hex 5/16-18 x 1-1/4
26	12697P1	Float, Mag Fiber Member
27	13500A1	Magneto Fairbanks Morse
28	159947	Screw Mach 10-24 x 3/4 Pan Hd.
29	19096P1	Cap, End
30	19097P1	Gasket, End Cap
31	19098P1	Ring, Folcrom Pin Snap
32	12479P1	Point Set, CW
33	436666	Screw Mach 6-32 x 5/8 Pan Hd.
34	159582	Screw Mach 8-32 x 3/8 Pan Hd.
35	131015	Washer Flat 3/16 x 7/16 x .049
36	19103P1	Wick, Cam CW
37	436691	Screw Mach 8-32 x 1/4 Pan Hd.
38	13909P1	Condenser
39	144722	Pan Head Self Tapping Screw
40	436859	Screw Mach 8-32 x 3/8 Phos. Coated
41	19100P1	Support, Bearing
42	19101P1	Bearing, Cam End
43	19102P1	Rotor
44	19104P1	Switch Assembly
45	19105P1	Screw Special 6-32 x 1/4
46	19106P1	Clip, Coil
47	13884P1	Coil
48	19107P1	Key
49	19108P1	Ring Bearing Snap
50	19109P1	Bearing, Drive End
51	19110P1	Ring, Snap, Shaft
52	19112P1	Housing
53	19113P1	Pin, Pawl Stop
54	94008930	Set Screw, Headless Slotted Cup Point
55	19115P1	Seal, Inner Washer
56	19116P1	Seal, Shaft
57	19117P1	Seal, Outer Washer

<u>NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
58	19118P1	Coupling Complete
59	19119P1	Pawl Snap Ring
60	19120P1	Pawl, Coupling
61	19121P1	Hub, Asm.
62	19123P1	Shell, Coupling
63	19124P1	Coupling Nut Lockwasher
64	19125P1	Nut Coupling
65	19126P1	Washer, Shell Flat
66	19127P1	Washer, Shell Felt
67	19128P1	Washer, Shell Cupped
68	19129P1	Screw Cupper Washer
69	20170P1	Drive Spring
70	436666	Switch Screw 6-32 x 5/8
71	20171P1	Wire Assembly
72	20172P1	Insulating Washer
73	20173P1	Insulating Lever
74	20174P1	Bracket
75	131094	No. 6 Spg. Lockwasher
76	134530	Mach. Nut
77	20175P1	Switch
78	10357P1	Band, Tank Bushing
79	13503P1	Bracket, Anchor
80	131095	No. 8 Spg. Lockwasher
81	13625P1	Bolt, Special 5/16-24 x 2-1/2
82	180122	Bolt Hex 3/8-16 x 1
83	10449P1	Gauge, Pressure
84	12724P1	Line, Fuel
85	13067P1	Elbow
86	12700P1	Line, Oil Intake Starter to Pump
87	12722P1	Filter, Oil
88	10150A2	Housing, Fan
89	10148A1	Tank
90	120393	Flat Washer 11/32 x 11/16 x .065
91	190139	Nut Lock 5/16-24 Washer Insert Hex
92	181596	Bolt Hex 5/16-24 x 7/8
93	120386	Flat Washer 5/16 x 47/64 x .065
94	10897P1	Bolt, Special Air Cleaner Mtg.
95	10898P1	Bracket, Air Cleaner Mtg.
96	10908P1	Spacer, .375 x .100 x 1.00
97	94194550	Nut Lock 5/16-18 Washer Insert Hex
98	5137P1	Shaft, Fan
99	12397P1	Blank, Fan Blade
100	138542	Washer Lock 3/8 Int Tooth
101	120369	Nut Hex 3/8-24
102	5133P1	Housing, Fan Bearing
103	5165P1	Spacer, Fan Bearing
104	5139P1	Bearing, Ball Fan
105	5134P1	Nut Fan Bearing
106	12709P1	Washer, Lock Fan Bearing
107	12696P1	Pulley Fan
108	120368	Nut, Hex 5/16-24
109	7354P1	Valve and Strainer
110	5163P1	Belt, Fan
111	12711P1	Deflector, Cylinder Air, Right Side

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
112	167257	Screw Tapping 1/4-20 x 1/2 Pan Hd.
113	10145A1	Bracket, Fan Housing Weldment
114	12712P1	Deflector, Cylinder Air, Left Side
115	10881P1	Deflector, Cylinder Head
116	12713P1	Spacer, Deflector
117	7216P1	Clamp, Fuel Hose
118	10896P1	Line
119	13031P1	Clamps
120	10902P1	Hose, Air Cleaner
121	13501P1	Elbow
122	12146P1	Pulley
123	20157P1	Front Oil Seal
124	12427P1	Retainer
125	20158P1	Cover & Bearing Assembly
126	12429P1	Shaft & Yoke
127	12433P1	Thrust Sleeve & Bearing
128	12435P1	Retainer
129	12425P1	Gasket, Body To Cover
130	454580	Screw & Ext. Lockwasher Asm. 6-32 x 5/16
131	20159P1	Lever Rocker
132	94242560	Washer, Lock No. 12 Extra Duty
133	94157850	Screw Mach. Hex 12-24 x 5/8
134	20160P1	Body, Assembly
135	20161P1	Seal, Oil Rocker Shaft
136	94194540	Nut Lock 1/4-20 Washer Insert Hex
137	20162P1	Shaft, Rocker
138	20163P1	Lever, Throttle
139	20164P1	Retainer
140	446143	Washer Flat 3/16 x 3/8 x .049
141	436728	Screw Mach 10-24 x 1/4 Pan Hd.
142	20165P1	Hub Cable Lock
143	12430P1	Retainer
144	12431P1	Pin, Pivot
145	12432P1	Flyweight
146	94228630	Pin Spring 5/32 x 1-1/8
147	20166P1	Plug, Pipe Special
148	20167P1	Tag, Oil Lever
149	12133P1	Mounting Bracket
150	20036A1	Governor Asm with Pulley
151	181573	1/4-28 x 1-1/4 Hex Hp Bolt
152	120380	1/4 Spring Type Lock Washer
153	120367	1/4-28 Hex Nut
154	94157960	1/4-20 x 5/8 HH Screw
155	12137P1	Governor Control Arm
156	12136P1	Governor Control Bracket
157	94133140	1/4-20 Type CL Hex Lock Nut
158	12135P1	Governor Control Link
159	12138P1	Governor Spring
160	12140P1	Carburetor BEE Crank
161	454065	10-32 x 3/4 Hex Hd. Mach Screw
162	120611	10-32 SQ. Nut
163	10945P1	Governor Throttle Rod
164	11881P1	Throttle Rod Clip
165	12710P1	Gasket
166	10899P1	Base, Air Cleaner Mtg.
167	10900P1	Element, Air Cleaner
168	10901P1	Cover, Air Cleaner

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
169	10905P1	Sealing Washer
170	120386	Washer, Flat 5/16 x 47/64 x .065
171	10413P1	Washer Insert Wing Nut 1/4-20
172	2505P1	Gas Tank Cap
173	1731P1	Spark Plug Wire
174	19182P1	Decal Safety First
175	10862P2	Air Cleaner Instruction Decal
176	94194550	Nut, Lock 5/16-18 Washer Insert
177	19961P1	Nipple, Magneto
N.S	19130P1	Coupling Complete
N.S	19122P1	Shell, Coupling
178	13452P1	Strap, Starting



ITEM
NO.

PART NO.

DESCRIPTION

1	180082	Bolt Hex 5/16-18 x 1-3/8
2	10894A1	Lever, Actuating Shaft
3	12322P1	Spacer, .343 x .562 x 1.080
4	12321P1	Arm, Shifter
5	120393	Washer Flat 11/32 x 11/16 x .065
6	12688P1	Handle, Right
7	10275P1	Wire, Stop Switch
8	8265P1	Grommet
9	12687P1	Handle, Left
10	180124	Bolt Hex 3/8-16 x 1-1/4
11	120382	Washer Lock 3/8 Sp
12	12704P1	Washer, Hood Spacer
13	12690P1	Bracket, Driving Handle
14	12689P1	Clamp, Handle
15	18150A1	Shifter, Rod Guide And Grommet Asm
16	12324P1	Clevis, Shifter Rod
17	12325P1	Grommet, Shifter
18	189304	Bolt Hex 3/8-16 x 3-1/4
19	456004	Nut Lock 3/8-16 Washer Insert Hex
20	12683P1	Lever, Clutch Hand
21	12684P1	Hand Lever Pivot
22	120393	Washer Flat 11/32 x 11/16 x .065
23	181623	Bolt Hex 5/16-24 x 2-3/4
24	190139	Nut Lock 5/16-24 Washer Insert Hex
25	120369	Nut Hex 3/8-24
26	19141P1	Rod, Clutch
27	189323	Bolt Hex 5/16-24 x 3-1/2
28	20008P1	Pivot Detent
29	274301	Ball, Steel 5/16
30	12586P1	Spring Comp Type 7/8 x .28
31	19144P1	Bracket
32	20009P1	Bushing .328 x .495 x 1.444
33	138078	Pin Clevis 3/8 x .948
34	121222	Pin Cotter 3/32 x .75
35	13038A1	Rod, Clutch Short
36	431780	Pin Clevis 3/8 x .750
37	10161A1	Hitch, Rear 7.6
38	12554P1	Brace, Rear Hitch
39	180121	Bolt Hex 3/8-16 x 7/8
40	138542	Washer Lock 3/8 Int Tooth
41	120377	Nut Hex 3/8-16
42	6027A1	Stand, Sprayer Tank
43	13457P1	Handle, Adjusting
44	10277P1	Switch, Stop
45	12323P1	Rod, Shifter
46	120394	Washer Flat 13/32 x 13/16 x .065
47	441256	10-24 Acorn Type Nut
48	13034P1	Grip, Handle Left
49	13035P1	Grip, Handle Right
50	19176P1	Decal, Gear Shift
51	19177P1	Decal, P.T.O. Choke
52	19178P1	Decal, Fwd/Rev Engine Stop
53	19179P1	Decal, Throttle
54	5167P1	Grip, Handle
55	8226P1	Lever, Throttle Control
56	436738	Screw Mach 10-24 x 1-1/2 Pan Hd

ITEM
NO.

PART NO.

DESCRIPTION

57	190254	Nut Lock Mach 10-24 Washer Insert Hex
58	7331P1	Clip Speed
59	7176P1	Bracket, Manual Choke
60	8225P1	Control Choke
61	12967P1	Bracket, Control
62	180022	Bolt Hex 1/4-20 x 1
63	94133140	Nut Lock 1/4-20 Type CL Hex
64	8260P1	Clip, Conduit
65	10911E1	Custom Hood Assembly
66	10912P1	Custom Convertible Hood Decal
67	120388	7/16 Flat Washer
68	8281P1	Hood Stop
69	120910	10-24 x 3/4 Pan Hd Slotted Mach Screw
70	120378	Nut Hex 1/2-13
71	180175	Bolt, Hex 1/2-13 x 1-1/4
72	120384	Washer Lock 1/2 Sp.
73	94194550	Nut Lock 5/16-18 Washer Insert Hex

Form No. 20595L1 (12-10-73) for Models

20241E1	20244E1
20242E1	20245E1
20243E1	20246E1

PRINTED IN UNITED STATES OF AMERICA